



Abyx Fit Silk
Manuel d'utilisation

VOTRE ABYX FIT SILK
FR
Écran tactile complet
Sensors
Points de charge

CHARGER VOTRE ABYX FIT CONNECT
Veuillez utiliser uniquement le chargeur fourni. Vous pouvez utiliser n'importe quel port USB alimenté pour connecter votre chargeur.

TÉLÉCHARGER L'APP ABYX FIT CONNECT
Téléchargez l'application ABYX FIT CONNECT sur l'app store pour les téléphones iOS et sur le Google Play Store pour les téléphones Android.

CONNECTER VOTRE ABYX FIT SILK
Veillez à bien charger votre montre avant l'appairage et assurez-vous d'avoir installé l'application ABYX FIT CONNECT.

RECONNECTER VOTRE MONTRE
Pour reconnecter votre montre, assurez-vous d'avoir oublié la montre dans vos paramètres bluetooth (voir ci-dessus) et ensuite suivez les étapes de la section CONNECTER VOTRE ABYX FIT SILK.

CARTE DES MENUS
Introduction
Vos notifications reçues sur votre smartphone.

MESSAGES & NOTIFICATIONS
Introduction
Vos notifications reçues sur votre smartphone. Faites glisser à droite l'écran principal pour consulter vos notifications.

PODOMÈTRE ET MONITEUR DE SOMMEIL
Podomètre
La montre compte automatiquement vos pas. Le nombre de pas est affiché dans le menu "Pas" de la montre et dans l'onglet "Accueil" de l'application.

MODES SPORTS
Introduction
Les modes sports sont lancés depuis la montre. Ils vous permettent d'estimer la durée de votre session de sport et les calories dépensées pour 10 activités sportives.

MONITEUR CARDIAQUE
Rythme cardiaque (bpm)
Faites défiler l'écran vers le bas jusqu'au menu BPM et appuyez sur l'écran pour déclencher la mesure.

MODE PHOTO, RÉINITIALISATION, VERSION
Déclencheur photo
Vous pouvez utiliser votre montre pour déclencher l'appareil photo de votre smartphone à distance.

MUSIQUE, TROUVER MA MONTRE / SMARTPHONE
Musique
Vous pouvez contrôler la musique jouée par votre smartphone depuis votre montre.

GÉRER LES NOTIFICATIONS & PERMISSIONS
Activer / désactiver les notifications
1. Ouvrez la section "Notifications" depuis les réglages de votre téléphone.

Économie d'énergie Android
1. Ouvrez la section "Batterie" depuis les réglages de votre smartphone.

Recyclage
Collecte sélective des déchets électriques et électroniques. Les produits électroniques ne doivent pas être mis au rebut avec les produits ménagers.



Abyx Fit Silk
User Manual

PRODUCT OVERVIEW
EN
Full touch screen
Charging points
Heart Rate
Sensors

CHARGE YOUR ABYX FIT SILK
Please use only the charger supplied with your Abyx Fit Silk to charge your watch. You can use any powered USB port to connect your charger.

DOWNLOAD THE ABYX FIT CONNECT APP
Download the ABYX FIT CONNECT app on the App store for iOS devices and on the Google Play Store for Android devices.

PAIRING YOUR ABYX FIT SILK
Please charge your watch before pairing and make sure you have the ABYX FIT CONNECT application downloaded.

HOW TO CHANGE THE HOME SCREEN/WATCH FACE
On the watch, navigate to the "More" menu and select "Watch Faces".

SCREEN MAP
Introduction
The Abyx Fit Silk displays the last five notifications received on your smartphone.

MESSAGES & NOTIFICATIONS
Introduction
The Abyx Fit Silk displays the last five notifications received on your smartphone.

STEP COUNTER AND SLEEP MODE
Step counter
The watch automatically records the number of steps taken during the day. The number of steps taken is displayed in the "Steps" menu of the watch and also in the "Home" tab of the app.

SPORT MODES
Introduction
Sport modes are only launched from the watch menu. They allow you to view and save your exercise duration and calories burned during your sports sessions.

HEART MONITOR
Heart Rate (bpm)
Swipe up and press the screen to have the watch record your heart rate. Heart rate data are shown in the "Home" tab of the app.

CAMERA, RESET, ABOUT
Camera
You can use your watch as a remote control to take photos on your smartphone.

MUSIC, FIND MY WATCH / PHONE
Music
You can control the music played by your smartphone from your watch.

MANAGE NOTIFICATIONS & PERMISSIONS
Turn apps notifications ON/OFF
In order for your watch to display the contents of the notification you must set your notification parameter so that the content of the notifications show on the lock screen and the status bar.

Android Notifications
1. Open your phone settings and go to the notifications section.

EU Declaration of Conformity
Hereby, Onyx Group Limited declares that the radio equipment type "Smartwatch" ABYX FIT SILK is in compliance with the Directive 2014/53/EU.